



Dash-Topper®

“World’s Finest Dashcover”

Thank you for your Dash-Topper® purchase!
Please keep these instructions for your Warranty.



INSTALLATION INSTRUCTIONS

1. PREPARING YOUR DASHBOARD: Your dashboard must be clean for the self-adhesive Velcro® to stick properly. Clean the surface of your dashboard using either soap and water or the enclosed moist towelette. If you have a protective coating on your dashboard, you may need a stronger cleaning agent to ensure the Velcro® sticks. Read and follow the cleaner’s directions regarding proper use.



2. POSITIONING YOUR DASH COVER:

Unroll your Dash-Topper® dash cover and allow it to lie flat on your dashboard. Shape it to conform to the contours of your dashboard while also aligning the vents and edges. Some dash covers may need to be tucked between the windshield and the dashboard to align properly. A small

plastic spatula works well for this. **NOTE: For Poly Carpet dash covers only,** spraying the surface with water will soften the nap, making it easier to form.




3. DEFROSTER VENTS AND SENSORS:

Holes should be precut on your dash cover if your vehicle has any of the following: Defroster Vents, Heads-Up Display (HUD), Forward Collision Warning (FCW), Light Sensor for automatic headlights, Climate Control Sensor for automatic temperature control or any other sensors. If you see that

there is no cutout for a sensor, check for markings on the underside of the dash cover. Ensure these markings are aligned with the sensor and carefully cut the opening using sharp scissors. If you don’t see any markings or do not feel comfortable cutting the sensor opening, please call customer service for help and advice.

NOTE: There are no cut outs for speakers, as Dash-Topper® dash cover fabrics are acoustically transparent and do not impede sound.

4. CUTTING THE VELCRO® STRIPS: Your dash cover will be fastened to the dashboard using Velcro® tabs which grip the back of the dash cover. Take the two long Velcro® strips and cut them into ½ inch wide pieces. When you are done cutting you should have a total of about 24 small tabs.



½ inch wide tabs

5. ATTACHING YOUR DASH COVER: Please do not skip this step. It's important that your dash cover be secured to the dashboard. With your dash cover in place, start by putting a ½ inch Velcro® tab near each corner of the dashboard underneath the dash cover. Lift the edge of your dash cover, peel off the Velcro® tab's backing paper and stick the adhesive side of the tab to your dashboard. Distribute the rest of the tabs at fairly even intervals along the outer edges and along the defroster vents and any other openings. As you position each tab, press the dash cover down on top of it. If you need to adjust the fit, simply lift the dash cover off the Velcro® tab, correct the position of the dash cover, then press it back down on the tab to reattach it. You may need to add tabs in some areas for a better fit. Use as many tabs as necessary to secure your dash cover.



Note: Velcro® goes on dashboard

6. PASSENGER SIDE AIRBAG: Your Dash-Topper® dash cover has been designed to allow for the proper deployment of the passenger airbag.

WARRANTY POLICY

Your Dash-Topper® Dash Cover is warranted against any material or manufacturing defects. **Poly Carpet carries a Lifetime Warranty; all other fabrics have a 5-Year Warranty.** If there is a defect, Dash-Topper® shall either repair or replace your dash cover. **Returns are not allowed on custom embroidery except for manufacturer's error.** Defects do not include damage due to improper handling during installation or normal usage. This warranty does not cover cigarette burns, damage from sharp objects, stains from food or beverages, ink, grease or other chemicals, or harsh cleaning agents including bleach. All warranties are subject to manufacturer's approval. This warranty does not cover other interior components, labor, personal injury, or any other damage or injury. This warranty is in lieu of any other expressed or implied warranties.

Please call us at **1-800-843-3274 ext. 1118** for a return authorization (RA) number before sending in any warranty claims. For warranty claims, the dash cover must be accompanied with proof of purchase, either a dated receipt or a copy of the front side of these instructions. If an RA is issued, the dash cover will need to be sent freight prepaid to Dash-Topper.

If you have any questions about your installation, call us toll-free at:



1-800-843-3274

Monday-Friday 8:00 am to 5:30 pm
Arizona Time

Scan this QR code to watch our
Dash Cover Installation video on
Dash Designs® YouTube channel


Dash-Topper
"World's Finest Dashcover"

Dash-Topper
615 W Knox Rd.
Tempe, AZ 85284

© 2022 Dash-Topper®, Inc.